

GAS CREPE MAKER

USER'S MANUAL

I . Basic parameter

Name	Gas Crepe Make
Model	CM-04-G
Dimension	400*400*200
Control switch number	1

II . Installation and precautions

1. Install the equipment in a place 10cm away from the wall and use is in a draughty place.
2. Do not put any flammable objects (like towel) on the stove or it may cause fire accident.
3. Do not use other type of gas as fuel.
4. Turn off the stove after using.
5. When you find the gas leaked, turn off the gas valve immediately and open the window. Do not turn on or off any power or inflame. Use it when it is repaired.

III. How to use

1. Connect with LPG source. Do not use before checking if it is well connected.
2. Open the LPG valve, rotate the switch in front of the stove slowly at counter-clockwise direction until you hear "di" sound and observe if the stove is light up. If not, you need to do it again until it is light up. It may take a long time to light up the stove if it has no been using for quite a period or using it for the first time.
3. When user finishes, rotate the switch clockwise to its end and turn off the adjustment valve of LPG.
4. When rotate the switch in front of the stove to direction of nine-clock, the fire is biggest. If not, fire is small.

Note:For the first time,the temperature should be adjusted to the maximum for about 10minutes.If there is odor or smoke,it is normal.